



LED Display FAQs

- **How can I sync the digital pace clock to the analog clock at my facility?**

When the LED is set to Pace Mode, wait until the swimming facility's pace clock is at the top/on the zero, then short press the bottom dial (Menu) to reset the LED clock to zero seconds.

- **My LED is frozen or not picking up the watch times**

Reboot the device by holding in both dials for about 10 secs until the reboot screen comes on and the status LED begins flashing rapidly.


If the LED hasn't been used in a long time or the battery has run completely flat and then left to charge, it may need a reboot to wake up again.

- **How do I change the clock time to match Daylight Saving hours?**

Plug in the USB cable into the LED and the other end into the computer. Open the Immerse Manager program to allow the LED time to update to the computer's time.

If your LED display is mounted to a wall, you can use your stopwatch to update the time; provided that both devices are on the same ID and Channel and that the stopwatch's time is correct.

The procedure to update the time on the stopwatch is the same as above. The USB cable will need to be plugged into the stopwatch and the computer with Immerse Manager open. The time will automatically update.



Now, run any mode from the stopwatch (watch, interval, pace). Once you close the timing, the time on the LED display will update.